



USER MANUAL – EN

IN 14652 Foot Massager inSPORTline Footsage



CONTENTS

SAFETY PRECAUTIONS..... 3
INSTRUCTIONS FOR USE..... 4
MAINTENANCE 5
 Storage..... 5
 Cleaning..... 5
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 5

SAFETY PRECAUTIONS

Read the manual carefully before using this product. Retain the manual for possible future use.

When using electrical products, especially with children around, you should always follow basic safety precautions, including those listed in this manual.

DANGER

To reduce the risk of an electric shock, follow the following precautions:

- Always unplug the unit from electrical outlet immediately after using it or before cleaning.
- Do not reach for a unit that has fallen into water. Unplug it immediately.

WARNING

To reduce the risk of burns, electric shock, fire or injuries, follow the following precautions:

- The appliance should never be left unattended when plugged in, especially when there are children present. When you are not using it, or are going to be handling it, unplug it first.
- Children and physically or mentally disabled people can only use the device under adult supervision.
- Do not use the massager outdoors.
- Only use the product for its intended purpose as described in this manual. Do not use attachments that are not provided with the device and not recommended by the manufacturer.
- Do not carry this unit by the supply cord or use the cord as a handle.
- Do not use the massager if the power cord or plug is damaged, not working properly, or if it has been dropped into water. In these cases, return the power cord to the service department.
- Keep the power cord away from heated surfaces.
- Do not block the ventilation openings of the device or place it on a soft surface where they may be blocked. Keep the openings free of hair, lint, etc.
- Never insert objects into the openings.
- Do not use the massager in areas where aerosol sprays are used or areas where oxygen is being administered.
- Do not use the massager under a blanket or a pillow. The device may overheat and cause fire, electric shock or an injury.
- To disconnect the device, turn both switches off and then remove the plug from the outlet.
- Use the heating function carefully, otherwise it may cause serious burns. Do not use it on oversensitive areas or areas with poor blood circulation.
- This product is not suitable for medical use. Its purpose is to provide a luxurious massage.
- Consult your physician before using the product if:
 - You are pregnant.
 - You have a peacemaker.
 - You have concerns regarding your health.
- This product is not recommended to be used by diabetics.
- Never cover the massager while it's turned on.
- Do not use the product for more than 15 minutes at the time. After 15 minutes, the device will shut down automatically.
- Extensive use could lead to overheating and short service life. Should the device overheat, turn it off and let it cool down before further use.

- Never apply this product on swollen and inflamed areas or open wounds.
- Do not use the product before going to bed. The massager has stimulating effect and can delay sleep.
- Never use the product while in bed.
- If the power cord is damaged, it must be replaced by the manufacturer, a service technician or another qualified person.

CAUTION: TO AVOID AN INJURY OR IRREPARABLE DAMAGE, ALWAYS REMAIN SEATED WHILE USING THE MASSAGER. NEVER STAND ON THE UNIT.


INSTRUCTIONS FOR USE

1. Plug the device into a 100 – 220 V outlet.
2. Do not use the massager with shoes on. It is highly recommended to use the massager while in socks.
3. Take a seat and place the massager in front of you on the floor.
4. To activate the massage, press the power button once (on the left). The button will light up in blue.

TIP: By changing the pressure your feet put on the massager, you will change the feel of the massage. If the massager tickles you, you need to apply more pressure or you may need to become accustomed to the sensation. If the massage feels too strong, you may need to lighten the pressure your feet put on the unit.

5. To turn on the heating function with the massage, press the heat button (on the right). The button will light up in red.
6. When you are finished, turn the unit off and unplug it. The massager is turned off by pressing the power button again.

NOTE: As a safety feature, the heating function cannot be used on its own.



MAINTENANCE

Storage

Place the massager in its box or in a safe, dry and cool place. Avoid contact with sharp edges or pointed objects. Do not wrap the cord around the unit, it could get damaged. Do not hang the unit by the power cord.

Cleaning

Before cleaning, unplug the unit and allow it to cool down. Clean only with a soft, slightly damp sponge. Never allow water or any other liquid to come into contact with the device.

- Do not immerse the massager in water or any other liquid to clean it.
- Do not use abrasive cleaning products, brushes or strong chemicals that might damage the product.
- Do not attempt to repair the massager. There are no user-serviceable parts. Per warranty terms, send the unit to the customer service department.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User’s fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks

- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT s.r.o.

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

INSPORTLINE s.r.o.

Headquarters, Warranty & Service centre: Elektrická 6471, 911 01 Trenčín, Slovakia

CRN: 36311723

VAT ID: SK2020177082

Phone: +421(0)326 526 701

E-mail: objednavky@insportline.sk

reklamacie@insportline.sk

servis@insportline.sk

Web: www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: